


Car Mount

Your Crusher Racer is a Monster Machine with big monster truck wheels. It has unique racing action as its tires grab the track. To make sure the Crusher Racer is snugly hugging the track for continuous racing action, you must first mount the vehicle onto the track as follows:

- 1. Connect the Car Mount to the Flex Track by inserting the Connection-Tab into the Connection-Slot at the beginning of a section of connected Flex Track links.
- 2. Tilt the blue Car Mount Stem to the side.
- 3. Slide the underside of the Crusher Racer over the Car Mount Stem so that it inserts in-between the two half-circle shapes.
- 4. Slide the car so that the front end of the car is now aligned with the Car Mount Connection Tab.
- 5. Click the activation button on the back of the Crusher Racer. Crusher will move forward as it hugs the track.



TurboTwist Racer – Battery Charging


\*Before charging, make sure the car is switched OFF.

- 1. Locate the **USB-C charging port** on the bottom of the TurboTwist Racer.
- 2. Connect the USB-C cable to the port.
- 3. Plug the other end of the cable into a power source, such as a USB power adapter/brick, power bank, or laptop USB port.

**Indicator Light:** A red light will turn on to show that the car is charging. The light will turn off once fully charged.



















- 4. Disconnect the USB-C cable when charging is complete. Your TurboTwist Racer is ready to go—no opening or battery installation required!

**TANGLE WARNING:** Keep wheels away from hair, loose clothing & jewelry.



Legend

\* Refer back to these identifying images and descriptions of the included pieces as you follow the instructions.

<div>CRUSHER RACER</div> <div></div>	<div></div> <div>ACTIVATION BUTTON</div> <div></div>	<div>BACK LIGHTS</div> <div></div>	<div>USB-C CHARGER</div> <div></div>
		<div>USB-C CHARGING PORT</div> <div></div>	
<div>FLEX TRACK</div> <div></div>	<div>FLEX TRACK [108 LINKS]</div> <div></div>	<div>TRACK CONNECTION TAB</div> <div></div> <div>TRACK CONNECTION SLOT</div>	
<div>LOOP</div> <div></div>	<div>LOOP TRACK [5]</div> <div></div>	<div>LOOP CONNECTION TAB</div> <div></div> <div>LOOP CONNECTION SLOT</div>	
<div>LOOP BASE [2]</div> <div></div>	<div>BASE CONNECTION TAB</div> <div></div> <div>BASE CONNECTION SLOT</div> <div></div>		
<div>CAR MOUNT</div> <div></div>	<div>CAR MOUNT STEM</div> <div></div>	<div>CAR MOUNT CONNECTION TAB</div> <div></div> <div>CAR MOUNT CONNECTION SLOT</div>	

REQUIRED FOR ASSEMBLY:

Important note before you begin: Adult assembly is required.

A rechargeable battery is included. Please see the instructions for charging the batteries (Page 4).

These instructions are designed to provide clear direction for the use and/or assembly of this product. We appreciate your feedback and we're here to help. If any part seems unclear or if the directions do not achieve the desired results, please let us know. Before leaving any product complaints or bad reviews, please contact our customer service team at - info@jitterygit.com and we'll do all we can to resolve your issue.

WWW.JITTERYGIT.COM | INFO@JITTERYGIT.COM | @JITTERYGIT

**JitteryGit**

INSTRUCTIONS SHEET IS PART OF THE SET AND MUST REMAIN WITH IT AT ALL TIME

ITEM: CRUSHER TURBOTWIST RACER  
Comply to ASTM F963 & CPSIA Toy Safety Standards  
December 2025, Batch# BH20251124  
SHANTOU, CHINA

MADE IN CHINA


Imported by: **JitteryGit**  
Address:  
4970 SW 52st Ave., Ste 324  
Davie, FL 33314-5531

8 50076 85807 0



## Track Assembly Do's and Don'ts


1. When connecting the Flex Track links together be sure to tilt the link so that the connection tab meets the connection slot at an angle.
2. Each connected link should sit on top of the previously connected link. Please follow this pattern throughout the entire track assembly process to ensure that the links remain flush with each other.
3. When connecting the Flex Track make sure to keep the pieces straight. Do not let the pieces spiral. This will ensure a smooth track surface for racing.



## Loop Assembly


**NOTE:** For each of the steps below, remember to apply gentle pressure as forced or hard pressure may damage the toy.

1. Take the two base pieces and attach them together in side-by-side position as shown. The upward ramps on each base must be facing in opposite directions. Fit the connector tabs into the connector slots until you hear a "click" sound. This means you have snapped the base pieces together correctly.
2. Attach the Loop Track pieces to the base pieces. First, attach a piece of Loop Track on one base side. Pick a base piece and insert the connector tab of a piece of loop track into its slots. Listen for a "click" to confirm the pieces have been snapped together correctly.
3. Attach a piece of Loop Track to the other base side following the same instructions above.
4. Go back to the first base piece and start adding additional pieces of Loop Tracks one on top of the other. Each time, listen for the "click sound" to ensure the pieces have been snapped together correctly.
5. Connect the last Loop Track to the loop track on the opposite side to close the loop.



## Loop Disassembly

1. To remove the base pieces, hold the base side in one hand and the connected loop track piece in the other hand. Gently pull the pieces inwards and away from each other to disconnect. Applying too much force or pressure can damage the toy.
2. To disassemble the loop pieces, gently bend the pieces inward until they release apart from each other. Applying too much force or pressure can damage the toy. You will hear a click sound as you disassemble the pieces.



## Endless Possibilities... Tips & Tricks


You can use different props to make your race track more exciting! For a few cool tricks grab the following items (not included): String, two full water bottles, small chair/stool, box, pillow, ruler.

1. Create a loop shape out of the tracks, then use the string to tie both edges to a full bottle of water.

**WARNING:** When you tie a string to the track make sure not to run the thread on top of the middle of the track where the car runs. The thread may tangle in between the wheels.



2. Place a ruler on top of a chair or box higher than the loop, place something heavy on top to make sure it's stable. Then tie the top of the loop to the ruler to hold a perfect circular shape.



3. Create elevations and slopes using different items in your room. Use your imagination!

\* **Note:** The car is able to climb and descent very steep slopes, however the track needs to be supported to create resistance.



## Make it Glow!



The blue Flex Track & Loop - glow in the dark! For a long-lasting glow in the dark effect, expose the Flex Tracks & Loop pieces to light for as long as possible. This can include indoor lights or natural light outdoors.

**Long exposure to light extends the glowing feature!**

