

DINO TRACK FOREST SET

BUILDING INSTRUCTIONS

7-03





PLEASE NOTE These revised instructions have been created to address customer concerns. They have been updated from previous versions.

We appreciate your feedback and we're here to help. Before leaving any product complaints or bad reviews, please contact our customer service team at - info@jitterygig.com and we'll do all we can to resolve your issue.

WWW.JITTERYGIG.COM | INFO@JITTERYGIG.COM | [f](https://www.facebook.com/jitterygig) [@JITTERYGIG](https://www.instagram.com/jitterygig)

JitteryGig®

LEGEND * Refer back to these identifying images and descriptions of the included pieces as you follow the instructions.

LOOP 	LOOP TRACK [X 5] 	CONNECTOR TAB  CONNECTOR SLOT 	LOOP BASE [X 2] 
TUNNEL & OVERPASS 	TRACKS HITCHES  TREE HOLES 	OVERPASS TRACK [X2] 	FLEX TRACK [144 LINKS] 
CARS 			

REQUIRED FOR ASSEMBLY:

For assembly, a Philips head screwdriver is needed but not included. A smaller screwdriver is recommended.

To operate the cars, two AA batteries are needed but not included. It is recommended to use strong batteries with long life from a well-known brand.

IMPORTANT NOTE BEFORE YOU BEGIN: ADULT ASSEMBLY IS REQUIRED



WARNING


CHOKING HAZARD - Small parts
Not for children under 3 years.

LOOP TRACK ASSEMBLY


NOTE: For each of the steps below, remember to apply gentle pressure as forced or hard pressure may damage the toy.

1. Take the two base pieces and attach them together in side-by-side position as shown. The upward ramps on each base must be facing in opposite directions. Fit the connector tabs into the connector slots until you hear a “click” sound. This means you have snapped the base pieces together correctly.

1.



2.




3. Next, attach a piece of loop track to the other base side following the same instructions above.

4. Go back to the first base piece and start adding additional pieces of loop tracks one on top of the other. Each time, listen for the “click sound” to ensure the pieces have been snapped together correctly.


5. Connect the last loop track to the loop track on the opposite side to close the loop.



3.



4.




5.

LOOP TRACK DISASSEMBLY


1. To remove the base pieces, hold the base side in one hand and the connected loop track piece in the other hand. Gently pull the pieces inwards and away from each other to disconnect. Applying too much force or pressure can damage the toy.

2. To disassemble the loop pieces, gently bend the pieces inward until they release apart from each other. Applying too much force or pressure can damage the toy. You will hear a click sound as you disassemble the pieces.

1.



2.



TUNNEL & OVERPASS ASSEMBLY

1. Insert trees into the cave's Tree Holes



2. Connect 12 links of Flex Track on top of the cave's Track Hitches. To create a consistent look for the bridge, we recommend using 12 brown track links to match the color of the Overpass Tracks.



3. Slide a long strip of Flex Track under the tunnel. Then Connect one Overpass Track piece to one side of the Flex Track placed on top of the tunnel. Connect the other Overpass Track piece to the other side of the Flex Track.



4. Connect Flex Track pieces to the end of each Overpass Track.

The Flex Track that is under the tunnel can be extended by attaching more Flex Track pieces on either end as you continue designing your own layout.



TREES AND FLAG CONNECTIONS


To decorate the top of the Tunnel overpass cave and the rocks with trees, simply take the stems at the bottom of the trees and insert them into the Tree Holes. Repeat the same process with the Flag by taking the bottom of it and placing it into a Tree Hole.



CARS BATTERY INSTALLATION

1. Flip car over and gently unscrew the screw located in the back of the car.

NOTE: It is important not to apply too much pressure when unscrewing. The child safety screws are delicate and can become stripped, unaligned, or break if the screwdriver is not gently turned.



2. Lift the battery compartment lid and insert 1 AA battery into position matching the battery's positive contact head to the appropriate receptor as shown inside the battery case.

NOTE: Test whether the battery has been inserted correctly. Press the activation button to see if the car lights up and makes sounds.



3. If the activation button test is successful, put the lid back down in place and listen for a loud click. This indicates the lid is back in place snugly and correctly. Do not screw the screw back in until you hear the loud click. If you have heard the click, gently screw the screw back into place.

NOTE: If the cover is not screwed back on so that it is flush flat to the bottom of the car, the car won't travel around the loop track correctly.

4. Repeat steps 1-3 with the second car.

TIRE REPLACEMENT:

If a tire starts losing its grip on the track, you can replace it with the included spare tires. Simply pull the previous tire off of the wheel and pull the new tire over the wheel.



STICKERS ASSEMBLY

MAKE IT GLOW!

Apply Glow in the Dark stickers to tracks and accessories. Just use your creativity!

NOTE: For a long-lasting glow-in-the-dark effect, expose the loop & train tracks with the GID stickers to light for as long as possible. This can include indoor lights or natural light outdoors. Long exposure to light extends the glowing feature.



INSTRUCTIONS SHEET IS PART OF THE SET AND
MUST REMAIN WITH IT AT ALL TIME

ITEM: DINOTRACK FOREST-SET

Comply to ASTM F963 & CPSIA Toy Safety Standards
May 2026, Batch# RTK-2605,
SHANTOU, CHINA

MADE IN CHINA

Imported by: JitteryGrit

Address: 4960 SW 52nd St Ste 407-408
Davie, FL 33314



JitteryGrit